



NEMI Tin Whisker Test Project

SMTA International

Irina Boguslavsky, NEMI Consultant

Chicago, IL

September 25, 2003



Tin Whisker Committees

- ***Tin Whisker Test Standards Committee (Test Group)***
 - ***First committee formed***
 - ***Objective to develop tests/test criteria for tin whiskers***
 - ***Subject of Today's report***
- ***Tin Whisker Modeling Group (Modeling Group)***
 - ***Formed to gain fundamental understanding of whisker formation***
- ***Tin Whisker Users Group (Users Group)***
 - ***Formed by large companies with high reliability products to look at mitigation techniques***

Connect with and Strengthen Your Supply Chain



NEMI Committee Structure

- ***Tin Whisker Test Standards Committee (Test Group)***
 - 42 companies including two governmental organizations
 - Nick Vo (Chair) – Motorola
 - Jack McCullen (Co-Chair) – Intel
 - Mark Kwoka (Co-Chair) – Intersil

- ***Tin Whisker Modeling Group (Modeling Group)***
 - 13 companies including one government organization.
 - George Galyon (Chair) – IBM
 - Maureen Williams (Co-Chair) – NIST
 - Irina Boguslavsky (Co-Chair) – EFECT, NEMI Consultant

- ***Tin Whisker Users Group (Users Group)***
 - Recently started in late 2002
 - 10 companies
 - George Galyon (Chair) – IBM
 - Richard Coyle (Co-Chair) – Lucent

Connect with and Strengthen Your Supply Chain



Test Team Members

- **Agilent**
- **Alcatel**
- **Allegro Microsystems**
- **AMD**
- **Analog Devices**
- **Boeing**
- **ChipPAC**
- **Cooper Bussmann**
- **Delphi Delco**
- **Engelhard Clal**
- **Enthone**
- **FCI Framatome**
- **Flextronics**
- **HP**
- **IBM**
- **Indium**
- **Infineon AG**
- **Intel (Co-Chair)**
- **Intersil (Co-Chair)**
- **IPC**
- **ITRI Soldertec**
- **Kemet**
- **Lockheed Martin**
- **Microchip**
- **Micro Semi**
- **Molex**
- **Motorola (Chair)**
- **NASA Goddard**
- **NIST**
- **NEMI**
- **On Semi**
- **Philips**
- **Raytheon**
- **Soldering Tech.**
- **Shipley**
- **Solectron**
- **ST Micro**
- **SUNY Binghamton**
- **SUNY Buffalo**
- **Technic**
- **Texas Instruments**
- **US Army**

Connect with and Strengthen Your Supply Chain



Test Committee Goals

- ***Objective:***
 - To identify an accelerated test method for whiskering by evaluating various known test methods.
- ***Scope of Work:***
 - ✓ Collect all existing test methods for whiskers
 - ✓ Evaluate theory behind whisker formation
 - ✓ Devise a test or tests to detect whisker formation
 - ✓ Evaluate the test method with known good and “bad” processes to prove suitability
 - Develop a test specification and provide it to IPC/JEDEC for release as an industry standard

Connect with and Strengthen Your Supply Chain



Summary of Phase 1 DOE

- **Samples (brass coupons and 8 lead SOICs) were prepared with bright Sn along with SnPb (control)**
- **Whiskers formed only on the bright Sn-plated coupons, and were few in number - much less than expected**
- **There were two possible explanations of low whiskering**
 - **the level of impurities and/or contamination were maintained very low (samples plated in the lab) and thus helped to retard whisker growth**
 - **when the terminations were formed the plating cracked reducing stress in the finish and thus helped to retard whisker growth**
- **The results of the Phase 1 study were inconclusive**

Connect with and Strengthen Your Supply Chain



Summary of Phase 2 DOE

Connect with and Strengthen Your Supply Chain



Phase 2 DOE Experimental Parameters

- Finishes
 - Matte pure tin plated from MSA and Sulfate baths
 - 90Sn/10Pb alloy as a control
- Plating done on production line and in laboratory
- Samples
 - Production type components (OLIN 194 Cu SOIC)
 - Passives (fuses)
 - Brass coupons (flat)
- Test Conditions (modified conditions from Phase 1)
 - Ambient exposure (30 C) for 5 months
 - Temperature + humidity exposure
 - (30 C/90%RH and 60 C/95%RH) for 4 weeks
 - Thermal cycling (500 cycles; -55 C to 85 C, 20 min cycle with 7 min dwell)
 - And a combination of all of the above conditions

Connect with and Strengthen Your Supply Chain



Phase 2 DOE Matrix

Legs	Temp Cycle	Temp	Humidity	Plating Site	Remarks
6	-	60	95	Supplier A	Temp&Humidity
7	-	60	95	Supplier B	Temp&Humidity
8	-	30C (Amb)	90	Supplier A	Humidity
9	-	30C (Amb)	90	Supplier B	Humidity
10	-55 to 85	30C (Amb)	90	Supplier A	Sequential T/C & Humidity
11	-55 to 85	30C (Amb)	90	Supplier B	Sequential T/C & Humidity
12	-55 to 85	Amb	Amb	Supplier A	Test T/C
13	-55 to 85	Amb	Amb	Supplier B	Test T/C
14	Amb	Amb	Amb	Supplier A	Ambient
15	Amb	Amb	Amb	Supplier B	Ambient

Connect with and Strengthen Your Supply Chain



Samples Tested in DOE 2

A: 2 to 3 μ m, Matte Sn (Sulphate) on OLIN194 Cu SOIC molded/singulated

B: 10 to 12 μ m, Matte Sn (Sulphate) on OLIN194 Cu SOIC molded/singulated

C: 2 to 3 μ m, Bright Sn on brass coupon

D: 10 to 12 μ m, 90Sn/10Pb on OLIN194 Cu SOIC molded/singulated (control)

E: 2 to 3 μ m, Matte Sn (MSA) on OLIN194 Cu SOIC molded/singulated

F: 10 to 12 μ m, Matte Sn (MSA) on OLIN194 Cu SOIC molded/singulated

Connect with and Strengthen Your Supply Chain



Plating Bath Control for Suppliers A and B

Supplier A										
Contaminations, ppm	Pb		Fe		Cu		Zn		Ni	
	t_o	t_e	t_o	t_e	t_o	t_e	t_o	t_e	t_o	t_e
Sulfate (samples A and B)	6	6.3	9.7	11.9	0.4	0.6	0.4	0.5	0.44	0.5
MSA (samples E and D)	N/A	N/A	5.2	5.2	0.7	0.7	0.6	0.7	0.41	0.48
Supplier B										
MSA (samples E and D)	8.2	8.3	13.9	15	0.3	0.3	0.3	0.3	10	13

t_o – before plating

t_e – after plating

Connect with and Strengthen Your Supply Chain









SEM Inspection Protocol: Report

- **Average number of whiskers from the three fields**
- **The length of the longest whisker found in those fields**
- **The the length of longest whisker found during 300x inspection of entire leadframe surfaces on all three devices/coupons**
- **The estimated grain size range of the deposit.**
- **In all reports include:**
 - The date of plating
 - The date, duration, and conditions of accelerated test/storage
 - The date of inspection

Connect with and Strengthen Your Supply Chain




Effect of Bath Chemistry (SOIC's)




Connect with and Strengthen Your Supply Chain




Types of Whiskers on DOE 2 Samples




Thin MSA, Supplier A
long whiskers
(60°C/95%RH storage only)



Thin MSA, Supplier B
no whiskers
(60°C/95%RH storage only)



Thick Sulfate
short whiskers
(temp cycle + ambient)




Thick MSA, Supplier A
many short whiskers
(temp cycle + 30°C/90%RH)


Connect with and Strengthen Your Supply Chain



Sample Set D: SnPb – No Whiskers



Secondary Electron Image



Backscattered Electron Image

Leg 13 D

Connect with and Strengthen Your Supply Chain



Crystal Orientation

- **Crystal orientation of tin deposits is perceived to be an important factor affecting whisker growth**
- **The combination of certain grain orientations may create conditions favorable for whisker formation**
- **Volume fractions of various orientations define deposit texture**
- **Highly textured deposits with one preferred orientation representing a large volume fraction suggested to be less prone to whisker due to low concentration of crystalline defects**
- **Crystal orientation can be characterized by Preferred Orientation Factor (P)**

Connect with and Strengthen Your Supply Chain



Preferred Orientation Factor

$$P(hkl) = \frac{I(hkl) / I_0(hkl)}{(1/n) \sum [I(hkl) / I_0(hkl)]}$$

Where

$P(hkl)$ = Preferred Orientation Factor

$I(hkl)$ = measured intensity of hkl reflections




$I_0(hkl)$ = theoretical intensity of hkl reflections

n = number of reflections used in analysis

Connect with and Strengthen Your Supply Chain



Effect of Bath Chemistry and Thickness



Connect with and Strengthen Your Supply Chain



Types and Volume Fractions of Various Preferred Orientations

	MSA Supplier A		MSA Supplier B		Sulfate	
	Thin	Thick	Thin	Thick	Thin	Thick
Preferred Orientation	[321]	[011]	[011]	[220]	[620]	[013]
% of highest Preferred Orientation Factor	58	45	43	68	58	88

Connect with and Strengthen Your Supply Chain



Whisker Test for Passive Components

- **Chip fuses were tested as passive components by a supplier of passives**
- **Fuses were barrel plated with nickel barrier layer (2.54-12.7 μm thick) and pure tin (2.54-15.24 μm thick)**
- **Test conditions**
 - Thermal cycling -40°C to $+90^{\circ}\text{C}$ followed by $60^{\circ}\text{C}/90\%\text{RH}$
 - Thermal cycling -40°C to $+90^{\circ}\text{C}$ followed by ambient
 - Temperature+humidity: $60^{\circ}\text{C}/90\%\text{RH}$
 - Ambient
- **No whiskers were found after 4 weeks of ambient and $60^{\circ}\text{C}/90\%\text{RH}$ exposure**
- **Whiskers of similar length and density were found after thermal cycling followed by both ambient and $60^{\circ}\text{C}/90\%\text{RH}$ exposure**

Connect with and Strengthen Your Supply Chain



Chip Fuse Whisker Test Results

Plating Group #	After 500 Temp Cycles (-40°C to 90°C)		After 500 Temp Cycles (-40°C to 90°C) & 4wks storage (60°C & 90%RH)	
	<i>Whisker Frequency 200µm x 260µm area</i>	<i>Max Length (µm)</i>	<i>Whisker Frequency 200µm x 260µm area</i>	<i>Max Length (µm)</i>
1	223	31	159	22
2	54	44	66	25
3	137	28	144	38
4	66	34	93	34
5	6	9	3	9

Connect with and Strengthen Your Supply Chain



Initial Findings

- In general, more whiskers grew with the -55C/85C temperature cycle method, followed by 60C/90%RH storage; some whisker growth was also observed with the ambient environment
- There is no indication in this experiment that thicker deposits are less prone to whisker
- Bath chemistry/plating process parameters seem to have the most significant influence on whiskering
 - Slight advantage of sulfate-based chemistry comparing to a good-practice MSA bath
 - Significant difference between two MSA-based processes from two suppliers
- All these observation may indicate that there are some unknown factors that have influence on whisker growth comparable with aging conditions
- Another conclusion maybe made that whisker growth phenomenon is multi-factorial event and the theory/model describing it should take into consideration numerous parameters

Connect with and Strengthen Your Supply Chain



Future Work and Concerns

- *Future work:*
 - **Validate and verify recommended test methods.**
 - **Perform tests to extended durations (establish end points for recommended test methods).**
 - **Attempt to identify test methods which can be correlated to application life (to attempt to define reliability and qualification tests).**
- *Concerns:*
 - **How do we correlate whisker tests to application life (proof of quality & reliability)?**
 - **How do we to utilize fundamental understanding to define an accelerated test?**
 - **Are the proposed mitigation techniques effective?**

Connect with and Strengthen Your Supply Chain



Phase 3 DOE – Validate and Verify

- **Tests:**
 - -55°C (+0, -10) / 85°C (+10, -0) air-air temperature cycle (20minutes/cycle) up to 3000 cycles (500 cycles check points)
 - 60°C, 90±5%RH temperature / humidity storage 9000 hrs (~1 year) with 1000 hr check points
 - Ambient storage (~23°C, ~60%RH) up to 18000 hours (~2 years) with 1000 hr check points
- **Samples:**
 - Leaded packages from assembly contractors (64 LQFP)
 - Sn, SnBi, SnCu and SnPb (control) finishes
 - Copper CDA194 and Alloy42 leadframes
 - For comparison include cells with
 - Matte Ni underplating
 - Fused (confirm melting) and/or annealed Sn
 - Hot-dipped Sn
 - JEITA test vehicle

Connect with and Strengthen Your Supply Chain




Whisker Definition

- **Purpose:**
To specify the physical and visual characteristics of a tin whisker **for use in inspection** (not intended as a metallurgical definition)
- **Tin Whisker:**
A spontaneous columnar or cylindrical filament, which rarely branches, of tin emanating from the surface of a plating finish.
- **NOTE, For the purpose of inspection tin whiskers have the following characteristics:**
 - *an aspect ratio (length/width) > 2;*
 - *can be kinked, bent, twisted;*
 - *generally have a consistent cross-sectional shape;*
 - *rarely branch;*
 - *and may have striations/rings around it.*


Connect with and Strengthen Your Supply Chain




Whisker Examples



**Hillocks
(Lumps)**



**Odd-Shaped
Eruptions (OSE)**




Needles


Connect with and Strengthen Your Supply Chain




Whisker Examples



**Consistent cross-section
(column)**



Striations




Rings


Connect with and Strengthen Your Supply Chain




Whisker Examples



Kinked



Branched



**Initiating from
Hillock**

Connect with and Strengthen Your Supply Chain



Inspection Protocol

- **Scope:**
 - Establish an inspection method to quantify the propensity of an electroplated lead finish to develop tin whiskers.
 - Examples of electroplated lead finish uses: terminals of ICs and passives, connectors, printed circuit boards, etceteras.
- **Purpose:**

To recommend the equipment, locations and area of inspection, sample size and procedure for inspection.
- **Equipment:**

Scanning Electron Microscope (SEM) is recommended for whisker inspection and verification.

Connect with and Strengthen Your Supply Chain




Inspection Protocol

- *Procedure:*
 - Use carbon tape, paint, or other conductive material to attach the sample to the work holder to prevent charging.
 - When handling the samples, care must be taken to avoid contact with the electroplated finish. Contact with the finish may detach whiskers.
 - Inspect each sample for whiskers at a magnification of 300X.
 - The samples should be mounted in the best position (maximize inspection areas and view of critical locations such as bends) for SEM inspection.
 - At each inspection:
 - Record the presence of hillocks, odd-shaped eruptions and whiskers (whiskers ≥ 10 microns in length or > 2 in aspect ratio).
 - Estimate and record the length of the longest whisker. Whisker length is measured from the termination/electroplate surface. Use higher power as necessary to determine length.
 - Record the whisker density representative of the level of whisker growth (number of whiskers within a $250\mu\text{m} \times 250\mu\text{m}$ area).

Connect with and Strengthen Your Supply Chain



SEM Inspection Set-up



Connect with and Strengthen Your Supply Chain




Inspection Protocol

- *Recommended Sample Sizes:*

- **Example: Leaded Packages**

Inspect all plated surfaces, as practical, of 3 leads on a minimum of 3 packages randomly chosen from the test samples.



Connect with and Strengthen Your Supply Chain




Inspection Protocol

- *Recommended Sample Sizes:*

- **Example: Test Coupons**

Inspect 3 locations on a minimum of 3 coupons randomly selected from the test samples. The area inspected at each location should be the field of view at 300x (approximate area 250 μm X 250 μm).



Connect with and Strengthen Your Supply Chain




Inspection Protocol

- *Recommended Sample Sizes:*

- **Example: Passive Chipcaps/resistors**

Inspect the 3 visible sides and end of each termination on a minimum of 3 samples selected at random.



Connect with and Strengthen Your Supply Chain



Overview of Committee Effort

- ***Direct:***
 - Completed two comprehensive matrices, Phase 1 and 2, both for ICs and Passives.
 - Identified three test methods recommended for plating finish development and characterization.
 - Proposed a definition for whiskers.
 - Developed an inspection protocol.
 - Initiated test method document for potential release by JEDEC.
 - Preparing matrix for Phase 3 DOE (validation and verification).
- ***Indirect:***
 - Generated considerable momentum to understand whiskers and tin plating globally.

Connect with and Strengthen Your Supply Chain



Recommended Test Method

- Prepared whisker test method for release by JEDEC.
- Purpose:
 - Provide test method to aid in the evaluation and development of plating finishes.
 - Provide an industry-standardized test for comparison of whisker-propensity for different plating systems and processes.
 - Not intended for use in reliability assessment or qualification.

Connect with and Strengthen Your Supply Chain



Recommended Test Method

- **Recommended Test Methods:**
 - **-55°C (+0, -10) / 85°C (+10, -0) air-air temperature cycle (20minutes/cycle)**
 - **60 + 5 °C, 93 +2, -3 % RH**
 - **20 - 25 °C, ~30-80% RH**
 - **All three tests are to be performed using separate samples**
 - **Each test condition is to be performed independently**

Connect with and Strengthen Your Supply Chain